




ASSEMBLY INSTRUCTIONS

**CARTER
ELECTRIC RECLINER
ARMCHAIR**




Carter Power Reclining Chair

Please follow these instructions carefully in order to ensure your new sofa is assembled in the correct manner.

Please do not use a sharp implement when unpacking your furniture as this may damage the fabric.


Please note that any creases in the fabric are as a result of the packaging and are perfectly normal. These will diminish over the first few weeks of use at room temperature.

STEP 1




Remove the chair back main cushion (x1) and transformer (x1) from the chair.

STEP 2




Ensure the connecting clips are aligned and then (with a person at each end) lower the back section into the base applying firm pressure until you hear a 'click' and the back is secure.

STEP 3



Attach the back cover to the velcro strip to secure.

STEP 4



Connect the cable from the chair into the transformer provided and plug into a standard mains socket.

STEP 5






Image of Assembled Chair.

STEP 6




Press the front button to recline your furniture.

STEP 7





Press the rear button to return to the upright position.



Please do not sit on the foot rest!

Reclining Sofa Seat Back Fitting Method



When fitting the sofa back ensure the connecting clips are aligned and then (with a person at each end) lower the back frame section into the base applying firm pressure until you hear a “click” and make sure the back is fixed.




WARNING: Before operating the reclining mechanism ensure that the surrounding area is clear.

WARNING: Risk of serious injury : keep hands, fingers, children and pets away from openings and moving parts.



ASSEMBLY INSTRUCTIONS

**CARTER
2 SEATER ELECTRIC
RECLINER SOFA**




Carter Power Reclining 2 Seater Sofa

Please follow these instructions carefully in order to ensure your new sofa is assembled in the correct manner.

Please do not use a sharp implement when unpacking your furniture as this may damage the fabric.


Please note that any creases in the fabric are as a result of the packaging and are perfectly normal. These will diminish over the first few weeks of use at room temperature.

STEP 1




Remove the chair back main cushion (x2) and transformer (x1) from the chair.

STEP 2




Ensure the connecting clips are aligned and then (with a person at each end) lower the back section into the base applying firm pressure until you hear a 'click' and the back is secure.

STEP 3



Attach the back cover to the velcro strip to secure.

STEP 4



Connect the cables from the sofa into the transformers provided and plug into a standard mains socket.

STEP 5






Image of Assembled Chair.

STEP 6




Press the front button to recline your furniture.

STEP 7





Press the rear button to return to the upright position.



Please do not sit on the foot rest!

Reclining Sofa Seat Back Fitting Method



When fitting the sofa back ensure the connecting clips are aligned and then (with a person at each end) lower the back frame section into the base applying firm pressure until you hear a “click” and make sure the back is fixed.




WARNING: Before operating the reclining mechanism ensure that the surrounding area is clear.

WARNING: Risk of serious injury : keep hands, fingers, children and pets away from openings and moving parts.



ASSEMBLY INSTRUCTIONS

**CARTER
3 SEATER ELECTRIC
RECLINER SOFA**




Carter Power Reclining 3 Seater Sofa

Please follow these instructions carefully in order to ensure your new sofa is assembled in the correct manner.

Please do not use a sharp implement when unpacking your furniture as this may damage the fabric.


Please note that any creases in the fabric are as a result of the packaging and are perfectly normal. These will diminish over the first few weeks of use at room temperature.

STEP 1




Remove the chair back main cushion (x2) and transformer (x1) from the chair.

STEP 2




Ensure the connecting clips are aligned and then (with a person at each end) lower the back section into the base applying firm pressure until you hear a 'click' and the back is secure.

STEP 3



Attach the back cover to the velcro strip to secure.

STEP 4



Connect the cable from the chair into the transformer provided and plug into a standard mains socket.

STEP 5






Image of Assembled Chair.

STEP 6




Press the front button to recline your furniture.

STEP 7





Press the rear button to return to the upright position.



Please do not sit on the foot rest!

Reclining Sofa Seat Back Fitting Method



When fitting the sofa back ensure the connecting clips are aligned and then (with a person at each end) lower the back frame section into the base applying firm pressure until you hear a “click” and make sure the back is fixed.



WARNING: Before operating the reclining mechanism ensure that the surrounding area is clear.

WARNING: Risk of serious injury : keep hands, fingers, children and pets away from openings and moving parts.