




# **ASSEMBLY INSTRUCTIONS**

**DEVON  
ELECTRIC RECLINER  
ARMCHAIR**




**Devon Power Reclining Chair**

Please follow these instructions carefully in order to ensure your new sofa is assembled in the correct manner.

Please do not use a sharp implement when unpacking your furniture as this may damage the leather.

Please note that any creases in the leather are as a result of the packaging and are perfectly normal. These will diminish over the first few weeks of use at room temperature.

**STEP 1**




Remove the chair back main cushion (x1) and transformer from the sofa.

**STEP 2**




Pull the cable through the back of the chair as shown above.

**STEP 3**




When fitting the chair back ensure the connecting clips are aligned and then (with a person at each end) lower the back section into the base applying firm pressure until you hear a "click" and the back is secure.

**STEP 4**




Connect both leads labelled 'headrest' together securing with attached clip.

**STEP 5**




Attach the leather cover at the back to the velcro strip to secure.

**STEP 6**




Connect the cable from the chair into the transformer provided and plug into a standard mains socket.

**STEP 7**




Press the front of the first button to recline your furniture.

**STEP 8**




Press the rear of the first button to return to the upright position.

**STEP 9**




Press the front of the second button to move the headrest forward.

**STEP 10**



Press the rear of the second button to return the headrest to the upright position.




Please do not sit on the foot rest!

\*Failure to correctly assemble your furniture may affect your warranty



# **ASSEMBLY INSTRUCTIONS**

**DEVON  
2 SEATER ELECTRIC  
RECLINER SOFA**




**Devon Power Motion Sofa**

Please follow these instructions carefully in order to ensure your new sofa is assembled in the correct manner.

Please do not use a sharp implement when unpacking your furniture as this may damage the leather.

Please note that any creases in the leather are as a result of the packaging and are perfectly normal. These will diminish over the first few weeks of use at room temperature.

**STEP 1**




Remove the sofa back main cushions (x2) and transformer from the sofa.

**STEP 2**




Pull the cables through the back of the sofa as shown above.

**STEP 3**




When fitting sofa backs ensure the connecting clips are aligned and then (with a person at each end) lower the back section into the base applying firm pressure until you hear a 'click' and the back is secure.

**STEP 4**




Connect both leads labelled 'headrest' together securing with attached clip.

**STEP 5**




Attach the leather cover at the back to the velcro strip to secure.

**STEP 6**




Connect the cables from the sofa into the transformer provided and plug into a standard mains socket.

**STEP 7**




Press the front of the first button to recline your furniture.

**STEP 8**




Press the rear of the first button to return to the upright position.

**STEP 9**




Press the front of the second button to move the headrest forward.

**STEP 10**



Press the rear of the second button to return the headrest to the upright position.




Please do not sit on the foot rest!

\*Failure to correctly assemble your furniture may affect your warranty



# **ASSEMBLY INSTRUCTIONS**

**DEVON  
3 SEATER ELECTRIC  
RECLINER SOFA**




**Devon Power Motion Sofa**

Please follow these instructions carefully in order to ensure your new sofa is assembled in the correct manner.

Please do not use a sharp implement when unpacking your furniture as this may damage the leather.


Please note that any creases in the leather are as a result of the packaging and are perfectly normal. These will diminish over the first few weeks of use at room temperature.

**STEP 1**




Remove the sofa back main cushions (x3) and transformer from the sofa.

**STEP 2**




Pull the cables through the back of the sofa as shown above.

**STEP 3**




When fitting sofa backs ensure the connecting clips are aligned and then (with a person at each end) lower the back section into the base applying firm pressure until you hear a 'click' and the back is secure.

**STEP 4**




Connect both leads labelled 'headrest' together securing with attached clip.

**STEP 5**




Attach the leather cover at the back to the velcro strip to secure.

**STEP 6**




Connect the cables from the sofa into the transformer provided and plug into a standard mains socket.

**STEP 7**



Press the front of the first button to recline your furniture.


**STEP 8**



Press the rear of the first button to return to the upright position.




**STEP 9**




Press the front of the second button to move the headrest forward.

**STEP 10**



Press the rear of the second button to return the headrest to the upright position.



Please do not sit on the foot rest!

\*Failure to correctly assemble your furniture may affect your warranty